

Measurement Guidelines

Atubi sizing chart to ensure correct support and comfort.

fig.1

LEG HARNESS MEASUREMENTS

- (a) Width from hip to hip
- (b) Thigh circumference





fig.2

BACKREST & CHEST HARNESS MEASUREMENTS

- (c) Shoulder to bottom
- (d) Chest circumference
- (e) For special vehicles:
Measure vehicle's backrest height.



	XS	S	M	L
A	23-30	28-38	30-40	34-55
B	33-53	42-67	54-86	72-110
C	<35	35-45	45-55	>55
D	<72	72-95	95-115	>115

*values in cm